

Getting Started Guide


IAR KickStart Kit™ for Fujitsu MB9BF516R

This guide briefly describes how to get started using IAR Embedded Workbench® for ARM with IAR J-Link OB (on-board) debug interface to run an example application on the MB9BF516R-SK target system.

For more detailed information, see the *IAR Embedded Workbench IDE User Guide* and the *C-SPY Debugging Guide*, which are available from the Help menu in the IAR Embedded Workbench IDE and IAR Information Center.

Features of the MB9BF516R-SK evaluation board

- MB9BF516R ARM 32-bit Cortex-M3 device
- J-Link-OB (J-Link for ARM is mounted on the evaluation board controlled via USB)
- Standard 20-pin JTAG connector
- Trace connector
- 3 choices of power supply: JTAG pin 19, Power jack, USB (On-board debugger)
- Power jack
- USB driver and connector (Host, Device)
- Reset button
- User button
- Power LED
- User LED
- Dimensions: 140 x 65 mm
- RoHS compliant



Install IAR Embedded Workbench for ARM

The installation DVD contains all the software and documentation you need to start building and running embedded applications on the MB9BF516R-SK evaluation board. We recommend that you follow the installation instructions on the DVD and use the default directories for installation.

- 1 Insert the installation DVD. The installation program will start automatically.
- 2 First choose which board you are working with, and then move on to the **CHOOSE SOFTWARE** page.
- 3 Select the IAR Embedded Workbench for ARM installation of your choice. We recommend the Kickstart edition which has no time limit.



Figure 1 - Choose software

- 4 You will be directed to an online Product Registration page to get your license number and key, which will be delivered to you via e-mail within a few minutes. After this you will be able to install the software. Note that it may take several minutes for the installation files to unpack.

Install the J-Link USB driver

Before you can use the J-Link OB over the USB port, the J-Link USB driver must be installed.

- 1 Connect your computer and the J-Link-OB(USB3) using the USB cable. The Power LED on the evaluation board should be lit.
- 2 If this is the first time that you are using the J-Link, Windows will start the Install wizard. Choose **Install from a specific location**. If the installation wizard does not start automatically, see note below.
- 3 When asked to locate the USB drivers, click the browse button and navigate to the `\IAR Systems\Embedded Workbench 6.x Kickstart\arm\drivers\JLink\x86` or `x64` directory, depending on your computer system.
- 4 Click **Finish**. The J-Link USB driver is now installed.

Note: If the installation wizard does not start automatically, or you get a message that the driver has not been installed properly, please navigate to `\arm\drivers\Jlink\` and start the `InstDrivers` application. This will install the J-Link USB driver and the LED should stay lit steadily.

Set up the evaluation board

After you have installed the software and the J-Link USB drivers, you need set the jumpers, see Table-2. The MB9BF516R-SK evaluation board can be powered from four different sources. You can select the power source by JP1.

- Power jack. Use an external power supply to feed 5V power $\overset{+}{\ominus}$ to the evaluation board.
- JTAG connector. Some debug probes, like IAR J-Link, supply 5V through pin 19.
- USB connector for on-board debugger (J-Link OB).

Run example projects

To take full advantage of the examples, you must have some working knowledge of IAR Embedded Workbench IDE. For a quick introduction, see the **GETTING STARTED** and the **TUTORIALS** in the **IAR Information Center for ARM**, see Figure-2.

- 1 From the **Start** menu, start IAR Embedded Workbench IDE by choosing **All Programs>IAR Systems>IAR Embedded Workbench for ARM 6.x Kickstart>IAR Embedded Workbench**. You will get straight into the **IAR Information Center for ARM**.
- 2 Click **EXAMPLE PROJECTS**.





Figure 2 - IAR Information Center for ARM

- 3 Select **Fujitsu>MB9BF51X> IAR MB9BF516R-SK** evaluation board.
- 4 Open an example project; for example, **Blinking LED** (click the  icon).
- 5 Choose a destination folder to save a copy of this project for testing, so that the original project will not be updated for any changes you made during testing.
- 6 Follow the instructions in the **Example description** to configure the board, and choose your build configuration, for example **RAM Debug**.









Figure 3 - Example description and Build configuration

- 7 Choose **Project>Make** or click the  button on the toolbar. The project should compile with no errors or warnings.
- 8 To download your program, choose **Project>Download and Debug** or click the  button.
- 9 The file `main.c` is now open in the editor window. Choose **Debug>Go** or click the  button to start the application.
- 10 To stop C-SPY, choose **Debug>Break** or click the  button.
- 11 To exit C-SPY, choose **Debug>Stop Debugging** or click the  button.
- 12 Now you can try other example projects included, just click **Help>Information Center** to bring up the **IAR Information Center** again.

MB9BF516R-SK evaluation board overview




Figure 4 - MB9BF516R-SK board layout

Connector description

| Connector | PCB | Description |
|-----------|------------|-------------------------------------|
| JTAG | JTAG | JTAG connector |
| TRACE | TRACE | TRACE connector |
| USB1 | USB Device | USB Device connector |
| USB2 | USB HOST | USB HOST connector |
| USB3 | USB | USB connector for on-board debugger |
| J1 | J1 | Pin header (MCU external pin) |
| J2 | J2 | Pin header (MCU external pin) |
| J3 | J3 | Power Supply 5V DC |

Table 1 - Connector description

Switches description

| Switches | Description |
|------------|---|
| DSW1 | 1: MD0 of MB9BF516R SW-ON: L, SW-OFF: H |
| | 2: MD1 of MB9BF516R SW-ON: L, SW-OFF: H |
| | 3: P21 of MB9BF516R SW-ON: L, SW-OFF: H |
| | 4: P22 of MB9BF516R SW-ON: L, SW-OFF: H |
| USB Select | Host / Device |
| RESET(SW1) | Reset button |
| USER(SW2) | User button |

Table 2 - Switches description

Jumper descriptions




Figure 5 - The MB9BF516R-SK evaluation board

Jumper description


| Jumper | PCB | Description |
|--------|--------------------|---|
| JP1 | OB JTAG JACK | USB 5V power supply JTAG 5V power supply (pin 19) Power jack 5V power supply |
| JP2 | | MCUVCC 3.3V/5V 1-2: +3.3V 2-3: +5V |
| JP3 | | Enabel Power supply for MCU ON (close) / OFF (open) |
| JP4 | GPIO USB | 1-2: use P81/UDP0 and P80/UDM0 pin as GPIO (P81, P80) 2-3: use P81/UDP0 and P80/UDM0 pin as USB (UDP0, UDM0) |
| JP5 | JTAG SEL | Select ICE (debugger) External JTAG ICE (close) / On-board debugger (open) |
| JP7 | | Connect P21 of MB9BF516R to DIP-SW (DSW1-3). |
| JP8 | | Connect P22 of MB9BF516R to DIP-SW (DSW1-4). |

Table 3 - Jumper description

External connectors description

JTAG

The JTAG connector allows the software debugger to communicate via a JTAG (Joint Test Action Group) port directly with the core. Instructions can be inserted and executed by the core thus allowing MB9BF516R memory to be programmed with code and executed step by step by the host software. For more details, refer to the IEEE Standard 1149.1 - 1990 Standard Test Access Port and Boundary Scan Architecture and MB9BF516R datasheets and its user manual.



| Pin # | Signal name | Signal type | Description |
|-------|-------------|-------------|---|
| 1 | VTreF | | Target reference voltage – Connected to +3.3V/+5V. |
| 2 | VCC | | Power supply – Computex ICE provide power through this pin |
| 3 | nTRST | Input | JTAG reset – The TRST pin can be used to reset the test logic within the Embedded ICE logic |
| 4 | NC | | |
| 5 | TDI | Input | Test Data In – This is the serial data input for the shift register. |
| 6 | NC | | |
| 7 | TMS | Input | Test Mode Select – The TMS pin selects the next state in the TAP state machine. |
| 8 | NC | | |
| 9 | TCK | Input | Test Clock – This allows shifting of the data input, on the TMS and TDI pins. It is a positive edge triggered clock with the TMS and TCK signals that define the internal state of the device. |
| 10 | GND | | |
| 11 | RTCK | | Return test clock signal – Some targets must synchronize the JTAG inputs to internal clocks. To assist in meeting this requirement, you can use a returned, and retimed, TCK to dynamically control the TCK rate. J-Link supports adaptive clocking, which waits for TCK changes to be echoed correctly before making further changes. Connect to RTCK if available, otherwise to GND |
| 12 | GND | | |
| 13 | TDO | Output | Test Data Output – This is the serial data output from the shift register. Data is shifted out of the device on the negative edge of the TCK signal |
| 14 | GND | | |
| 15 | nRST | | Target CPU reset signal. Typically connected to the RESET pin of the target CPU, which is typically called nRST, nRESET or RESET. |
| 16 | GND | | |
| 17 | NC | | |
| 18 | GND | | |
| 19 | VCC | | Power supply - J-Link or some other ICE provide power through this pin. |
| 20 | GND | | |

Table 4 - JTAG signals and descriptions

Trace connector

| Pin # | Signal name | Signal type | Description |
|------------|--------------|-------------|--|
| 1 | VTreF | Output | Target reference voltage - Connected to +3.3V/+5V. |
| 2 | SWDIO/TMS | I/O / Input | Serial wire data input / output / JTAG mode set - Connected to SWDIO/TMS of MB9BF516R. |
| 4 | SWCLK/TCK | Input | Serial wire clock / JTAG clock - Connected to SWCLK/TCK of MB9BF516R. |
| 6 | SWO/TDO | Output | Serial Wire Output trace port / Test data out - Connected to SWO/TDO of MB9BF516R |
| 8 | TDI | Input | JTAG data input - Connected to TDI of MB9BF516R. |
| 10 | nRESET | Input | JTAG reset - Connected to RESET of MB9BF516R. |
| 12 | TRACECLK | Output | Trace clock - Connected to TRACECLK of MB9BF516R |
| 14 | TRACEDATA[0] | Output | Trace data pin 0 - Connected to TRACE0 of MB9BF516R |
| 16 | TRACEDATA[1] | Output | Trace data pin 1 - Connected to TRACE0 of MB9BF516R |
| 18 | TRACEDATA[2] | Output | Trace data pin 2 - Connected to TRACE0 of MB9BF516R |
| 20 | TRACEDATA[3] | Output | Trace data pin 3 - Connected to TRACE0 of MB9BF516R |
| 7,11,13, | NC | | |
| 3,5,9,15,1 | GND | | |
| 7,19 | | | |

Table 5 - Trace signals and descriptions

USB Connector (USB1:USB-Device)

| Pin # | Signal name | Signal type | Description |
|-------|-------------|--------------|-----------------------------------|
| 1 | VBUS | Input | Connected to P60-pin of MB9BF516R |
| 2 | USB1_N | Input/Output | USB Data- |
| 3 | USB1_P | Input/Output | USB Data+ |
| 4 | NC | | |
| 5 | GND | | GND |
| 6 | SHIELD | | |

Table 6 - USB signals

USB Connector (USB2:USB-HOST)

| Pin # | Signal name | Signal type | Description |
|-------|-------------|--------------|-------------|
| 1 | VBUS | Output | USB +5V |
| 2 | USB2_N | Input/Output | USB Data- |
| 3 | USB2_P | Input/Output | USB Data+ |
| 4 | GND | | GND |
| 5 | SHLD1 | | |
| 6 | SHLD2 | | |

Table 7 - USB signals

USB Connector for On-board Debugger (USB3)

| Pin # | Signal name | Signal type | Decription |
|-------|-------------|--------------|------------|
| 1 | VBUS | Input | +5V Input |
| 2 | USB3_N | Input/Output | USB Data- |
| 3 | USB3_P | Input/Output | USB Data+ |
| 4 | NC | | |
| 5 | GND | | GND |
| 6 | SHIELD | | |

Table 8 - USB signals for On-board debugger

MCU External pin 1 (J1: Pin header)

| Pin # | Signal name | Pin # | Signal name |
|-------|-------------|-------|-------------|
| 1 | MCUVCC | 31 | MCUVCC |
| 2 | P50 | 32 | P40 |
| 3 | P51 | 33 | P41 |
| 4 | nUFLG | 34 | P42 |
| 5 | P53 | 35 | P43 |
| 6 | P54 | 36 | P44 |
| 7 | P55 | 37 | P45 |
| 8 | P56 | 38 | NC |
| 9 | P57 | 39 | NC |
| 10 | P58 | 40 | NC |
| 11 | P59 | 41 | NC |
| 12 | P5A | 42 | NC |
| 13 | P5B | 43 | nRES |
| 14 | P30 | 44 | P48 |
| 15 | P31 | 45 | P49 |
| 16 | P32 | 46 | P4A |
| 17 | P33 | 47 | P4B |
| 18 | P34 | 48 | P4C |
| 19 | P35 | 49 | P4D |
| 20 | P36 | 50 | P4E |
| 21 | P37 | 51 | P70 |
| 22 | P38 | 52 | P71 |
| 23 | P39 | 53 | P72 |
| 24 | P3A | 54 | P73 |
| 25 | P3B | 55 | P74 |
| 26 | P3C | 56 | MD1 |
| 27 | P3D | 57 | MD0 |
| 28 | P3E | 58 | NC |
| 29 | P3F | 59 | NC |
| 30 | GND | 60 | GND |

Table 9 - Signal description


MCU External Pin 2 (J2: Pin header)

| Pin # | Signal name | Pin # | Signal name |
|-------|-------------|-------|-------------|
| 61 | MCUVCC | 91 | MCUVCC |
| 62 | P10 | 92 | TRST |
| 63 | P11 | 93 | TCK |
| 64 | P12 | 94 | TDI |
| 65 | P13 | 95 | TMS |
| 66 | P14 | 96 | TDO |
| 67 | P15 | 97 | TRACE0 |
| 68 | P16 | 98 | TRACE1 |
| 69 | P17 | 99 | TRACE2 |
| 70 | AVCC | 100 | TRACE3 |
| 71 | AVRH | 101 | TRACECLK |
| 72 | AGND | 102 | P0A |
| 73 | P18 | 103 | P0B |
| 74 | P19 | 104 | P0C |
| 75 | P1A | 105 | P0D |
| 76 | P1B | 106 | P0E |
| 77 | P1C | 107 | P0F |
| 78 | P1D | 108 | P68 |
| 79 | P1E | 109 | P67 |
| 80 | P1F | 110 | P66 |
| 81 | P28 | 111 | P65 |
| 82 | P27 | 112 | P64 |
| 83 | P26 | 113 | P63 |
| 84 | P25 | 114 | nUBPON |
| 85 | P24 | 115 | P61 |
| 86 | P23 | 116 | P60 |
| 87 | P22 | 117 | USBVCC0 |
| 88 | P21 | 118 | UDM0 |
| 89 | P20 | 119 | UDP0 |
| 90 | GND | 120 | GND |

Table 10 - Signal description

Power jack (J3)

There is a standard 2.1 mm power jack mounted on the board. The power input should be DC +5V.



| Pin # | Signal name | Description |
|-------|-------------|-------------|
| 1 | Power input | +5V |
| 2 | GND | GND |

Table 11 - Power jack signals and descriptions

Creating a new application

You can create new application as following procedures without an example application.

1 Select **Project > Create new project**




Figure 6 - Create a new project

2 Click on the + mark on the left side of C in the project template




Figure 7 - Select Create a C project

3 Select **main** and click **OK**.




Figure 8 - Create a C project

Designate a folder where this project is stored and click **Save**. In this example a project named **NewProject** is created.




Figure 9 - save your new project

- The new project has been created.




Figure 10 - The new project have been created

- Edit the main program




Figure 11 - Edit the main program

6 Select File > Save Workspace




Figure 12 - Save Workspace

- 7 The **Save Workspace As...** screen is shown. Enter the name of your project, in our case `NewProject`, which name is same as the name of the project. Click **Save**.




Figure 13 - Save Workspace As...

8 Click **Project > Option** to select the correct options for your project




Figure 14 - Setting the project options

9 Select a device in **General Option** and the **Target** tab, click 




Figure 15 - Select a device

10 Select Fujitsu MB9BF516R




Figure 16 - Select your device

11 Confirm that Fujitsu MB9BF516R is selected.




Figure 17 - Confirm your device

- 12 Select and set the linker configuration file (.icf file). Change to **Category: Linker**.
- 13 If you select the default .icf file for your device, open the **Config** tab and check the **Override default** option.




Figure 18 - Confirm your device

- 14 If you select your original setting, make a copy of the template linker command file from \IAR Systems\Embedded Workbench 6.x Kickstart\arm\config\generic_cortex.icf to your stored folder and rename it as MB9BF516R.icf.
Or, make a copy of the template linker command file from \IAR Systems\Embedded Workbench 6.x Kickstart\arm\config\linker\Fujitsu\mb9bf516r.icf to your stored folder and rename it as MB9BF516R.icf.
- 15 Change to **Category: Linker**, open the **Config** tab and check the **Override default** option.





Figure 19 - Setting the Linger configuration file

- 16 Write `$(PROJ_DIR)` in the **override default** text box, and click . `$(PROJ_DIR)` mean that it is found in the project folder.




Figure 20 - Use the linker in the project folder

- 17 Select `MB9BF516R.icf` which you earlier created and click **Open**.




Figure 21 - Select the linker file in your project folder

18 Click **Edit** to edit the linker configuration.




Figure 22 - Edit the linker file

19 The **Linker configuration file editor** is shown and you should enter the following:




Figure 23 - Setting the Vector Table




Figure 24 - Setting the ROM/RAM address




Figure 25 - Setting the Stack/Heap sizes

After you are done with the linker configuration file editor, click on **Save**.

20 It is now time to build the project by clicking on the **Build** button.



Figure 26 - Build your project

21 After correcting possible errors in your code it is time to define your debugger as J-Link. Open **Project > Option > Category: Debugger**, open the **Setup** tab and change the driver to **J-Link/J-Trace**.




Figure 27 - Setting the debugger option

- 22 Open the **Download** tab and check **Verify download** (red circle), then check the **Use flash loader(s)** (blue circle), because this example uses flash area.




Figure 28 - Debugger download settings

- 23 Open **Category: J-Link/J-Trace** and the **Connection** tab. Select **SWD** in the **Interface** option.




Figure 29 - Setting the debug interface

24 Open the **Setup** tab and set the SWD speed. Click **OK**.




Figure 30 - Setting the debug speed

25 The project options have now been set and you can start C-SPY and debug your program.




Figure 31 - Start debugging

Disclaimer

Information given in this document is intended as a help for the user. IAR Systems shall not be held liable for any losses or problems arising from using the information given in this document. Neither whole nor any part of the information in this document may be adapted or reproduced.

Troubleshooting

If you are unable to find the cause of a problem, try resetting the evaluation board by using the reset button on the board. Then restart the C-SPY Debugger in the IAR Embedded Workbench IDE. You can also try disconnecting and reconnecting the power to the evaluation board, pressing the reset button and then restarting C-SPY.

| IAR KickStart Kit content | Trademarks etc. |
|--|--|
| <ul style="list-style-type: none"> • Installation DVD • IAR MB9BF516R-SK evaluation board • USB cable | <p>IAR Systems, IAR Embedded Workbench, C-SPY, IAR visualSTATE, The code to Success, IAR Kickstart Kit, IAR and the IAR Systems logotype are trademarks or registered trademarks owned by IAR Systems AB.</p> <p>All other trademarks or registered trademarks mentioned in this document are the properties of their respective owners.</p> <p style="text-align: center;">© Copyright 2012 IAR Systems AB.</p> <p style="text-align: center;">Part number: GS-MB9BF516R-2 Second edition: August 2012.</p> |