

# BOTTOM LEFT

9	10	11	12	13	14	15	16
TRIGGER ENBL	TRIGGER CC NR	QUANTIZATION	QUANT MIXER	TRACKMODE T1	TRACKMODE T2	TRACKMODE T3	TRACKMODE T4
WAVE	GAIN	RATE	OFFSET				
17	18	19	20	21	22	23	24
MIDI OUT AB T1	MIDI OUT CH T1	MIDI OUT AB T2	MIDI OUT CH T2	MIDI OUT AB T3	MIDI OUT CH T3	MIDI OUT AB T4	MIDI OUT CH T4
25	26	27	28	29	30	31	32
MIDI CTRL $\alpha$ T1	MIDI CTRL $\beta$ T1	MIDI CTRL $\alpha$ T2	MIDI CTRL $\beta$ T2	MIDI CTRL $\alpha$ T3	MIDI CTRL $\beta$ T3	MIDI CTRL $\alpha$ T4	MIDI CTRL $\beta$ T4